

LOVIBOND® WATER ANALYSIS

TINTOMETER® GROUP



Lovibond® ShuddhCheck™

Your gateway to better Water Testing

INSTRUCTION GUIDE- Nitrate CDR Method Colour Card

WORKING RANGE: 0 - 150 mg/l (ppm)

MEASURING RANGE: 0, 10, 25, 45, 75, 100, 125, 150 ppm as NO₃



Test Procedure

1. Take 10ml of water sample in the glass vial
2. Add one leveled scoop of black spatula No.2 provided with the kit (0.1gm) of Cadmium powder reagent to the vial and cap it and mix well for 1 minute
3. Allow it to stand for 5 more minutes.
4. Notice the colour change and compare it with the colour card provided with the kit
5. The matching colour corresponds to nitrate in mg/l in the water sample

This will give the Nitrate value directly as NO₃ in ppm of the water sample

No. of Tests: 100

Order Code: IN415290MK

Reorder Code: IN415291MKR

Tintometer India Private Limited

Door No. 7-2-C-14, 2nd, 3rd & 4th Floor

Sanathnagar Industrial Estate | Hyderabad-500018

Telangana | India



Notes

- * Cleaning: Thoroughly rinse out sample container after use.
- ** Test reagents are for chemical testing only. Not meant for human consumption; Keep out of reach of children. For industrial use only.



For more information please reach out to us:

📞 1800 599 3891/92 | ✉ indiaoffice@lovibond.in | 🌐 www.lovibond.in

🌐 <https://in.linkedin.com/company/tintometer-india-private-limited>