

LOVIBOND® WATER ANALYSIS

TINTOMETER® GROUP



Lovibond® ShuddhCheck™

Your gateway to better Water Testing

INSTRUCTION GUIDE- TOTAL ALKALINITY Drop Test

Working Range: 0 – 1000 mg/l (ppm)



Test Procedure

1. Take 2 ml water sample in a glass vial
2. Add 1 drop Total Alkalinity reagent No. 1 and mix well. The colour will change to blue
3. Add Total Alkalinity reagent No. 2 drop wise until the colour changes from blue to pale yellow
4. Make sure to count the number of drops added and mix the solution by swirling in the glass vial after each drop
5. To obtain the Total Alkalinity in water in ppm as CaCO_3 multiply the number of drops that were added in step 3 by factor 40
This will give the Total Alkalinity value directly in mg/l (ppm) in that water sample.

No. of Tests: 100

Order Code: IN416050MK

Reorder Code: IN416051MKR

Tintometer India Private Limited

Door No. 7-2-C-14, 2nd, 3rd & 4th Floor

Sanathnagar Industrial Estate | Hyderabad-500018

Telangana | India



Notes

- * Cleaning: Thoroughly rinse out sample container after use.
- ** Test reagents are for chemical testing only. Not meant for human consumption; Keep out of reach of children. For industrial use only.



For more information please reach out to us:

☎ 1800 599 3891/92 | ✉ indiaoffice@lovibond.in | 🌐 www.lovibond.in

🌐 <https://in.linkedin.com/company/tintometer-india-private-limited>